

ALPHA X

APPLICATION GUIDE



ALPHA

IMPORTANT INFORMATION

PACKAGING

1000ml Kit

MIX INSTRUCTIONS

Mix / Shake well prior to use.
3 Coat - 1 System Application

COVERAGE

Approximately 16-18 sqm
(Dependent on concrete porosity)

DESCRIPTION

Alpha X is a specially formulated single component sealer that provides excellent stain and abrasion resistance. Alpha X is a high-performance, satin sealer designed for use on concrete countertops, furniture and concrete art.

SURFACE PREPARATION

Surface preparation is a crucial first step to ensure optimal results. Concrete surface must be clean and free from dust, dirt and other particles. Ensure your concrete is completely dry, prior to sealing

OPTIMAL CURING TEMPERATURE

Sealer is best applied between 16-24 degrees Celsius.

CAUTIONS

Avoid contact with skin and eyes. Avoid breathing dust, fume, gas, mist, vapour or spray. Wear overalls, safety shoes, impervious gloves and safety glasses. Use only in well ventilated areas. Wash hands after use. Keep containers closed when not in use. Keep out of reach of children.

REQUIRED TOOLS

- Measuring devices
- Mixing containers
- Drill with mixing paddle
- 4mm nap rollers
- Lint free shop towels
- Acetone
- Clean water
- Timer

PRODUCT STORAGE

- Store in a cool, dry place.
- Keep product out of direct sunlight.
- Do not store in a refrigerator/freezer.
- Under these conditions, Alpha X has a shelf life of 12 months for unopened containers and 3 months for opened containers.

INSTRUCTIONS

APPLICATION

Mixing Alpha X

1. Shake well prior to use
2. Measure out required Sealer. Replace lid on container immediately.

Primer Coat (if applicable)

Alpha X, can be diluted if required
- 4 Parts Alpha X : 1 Part Xylene

Application

3. Pour sealer mixture onto concrete and use a nap roller to spread product.
4. Spread the sealer across concrete surface and move for approximately 1/2 - 1 minute. Do not let the mixture dry out. Take care with sides and angled surfaces as drips may stain.
5. Use a glove to wring excess mixture from roller and backroll to ensure even coverage. Be careful not to over backroll.
6. Allow to dry for 15-30 minutes.

Note: If streaking occurs, sand out prior to applying additional coats.

7. Repeat steps 3-6 twice

- Recommended 3 coats for optimum performance

NOTE: For further information or for technical support, contact Domcrete GFRC Countertop Supplies at info@domcrete.com.au or by calling 1300 132 679.